


USER MANUAL WIRELESS MOTION SENSOR




1.Place the batteries in the battery compartment.

→sensors →ADD device.

4. Open your control station App and press on settings →devices




5.Once the Device is succesfully added , The LED will stop flashing and the device can be seen in you APP.



Trouble Shooting:

***To reset the sensor press the button behind the hole on the side of the sensor for approximately 3 sec with the included pin.



LED FUNCTION TABLE	
Connection mode	LED will flash once per second for approximately 1 min.(After 1 min the LED will stop flashing)
Connection successfully	LED will stop flash.(The App will also indicate when the connectionis successful)
Sensorreset	LED will flash fast.(for 2 seconds)
Sensor triggered (when the sensor is opened for more than 10mm)	LED will flash once.



www.adurosmart.com_manuals_motion sensor