








ENDURA® STYLE

SOLAR TOSSA WALL



	EAN	W	lm light source	lm output	K	 (°C)	IP	V _{DC}	mA	
ENDURA STYLE SOLAR TOSSA WALLSEN830	4099854455698	6	650	500	3000	-20...+40	44	3.7	1420	12500

ENDURA® STYLE SOLAR TOSSA WALL



ENDURA® STYLE
SOLAR TOSSA WALL



5

1. Press for 3s

2. Press for 1s

ON

OFF

Mode 1

Mode 2

Mode 3

6

Mode 1

200lm

Mode 2

15s @ 300lm

75lm

15s @ 500lm

7

LUX

0-50 lux

ON

LUX

50-100 lux

OFF

2m

90°

max. 6m

8 Charging

In shade will not charge fully

Battery not replaceable

Icons: No open flame, Temperature, Warning, Sun, Snow, Temperature, +40°, -20°, Checkmark



IP44



FR
Cet appareil et
ses accessoires
se recyclent

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



OU

Points de collecte sur www.quefairedemesdechets.fr



LEDVANCE SASU
CQM, 5 rue d'Altorf
67120 Molsheim France
www.ledvance.com

GB LEDVANCE Ltd, Sterling House,
810 Mandarin Court, Warrington,
Cheshire, WA1 1GG, United Kingdom

G11219134
23.01.2025