SMART TAG

X6602




XENON SMART

Technical Specifications

Battery	:	1 x CR2032
Dimensions	:	37 mm*37mm*8mm
Weight	:	11 g
Power Consumption	:	5μA (Standby), / ≤ 10μA (Max.)
Range	:	≥ 40m (Outdoor Area)
Operating Temperature	:	-5 C° to +40 C°
Operating Humidity	:	≤ 95%

Button Functions



1. Turning on the Device

While the device is off, press and release the button once. When the device successfully turns on, it will play a short sound.

2. Turning off the Device

Press and hold the button for 3 seconds when the device is turned on. The device will "beep" 2 times when successfully turned off.

3. Resetting the Device to the Factory Settings


Press and release the button four times rapidly, then press it a fifth time and hold it until you hear a sound. After the beep sound, the device will reset to the factory settings.

Pairing the Device


1. Turn on the device. Press and release the button once to turn on the device. When the device is turned on successfully, it will play a short sound.




2. Launch the "Find My" app on your iPhone/iPad.




3. Tap the Items tab.




4. Tap the "Add Item" or "+" button.




or




5. Tap the "Other Supported Item" or "Add Other Item" button.




or




6. When your device is found, tap the "Connect" button.




7. Assign a name to your device and tap the "Continue" button.



8. Select an emoji for your device and tap "Continue".




9. Please read the information and tap the "Agree" button.



Find My App


1. Locating the Device

The "Find My" app can help you locate your device using the global network of hundreds of millions of iPhones, iPads, and Macs, even if your device isn't nearby. Your device securely sends its location to iCloud, allowing you to track its location through the "Find My" app. To protect your privacy, all data is shared anonymously and encrypted.




2. Play Sound

Select your device by following the steps Find -> Items on your iPhone/iPad. Then tap the "Play Sound" button.




3. Enabling Lost Mode


Select your device by following the steps Find -> Items on your iPhone/iPad.




Scroll down the screen and tap the "Enable" button under the "Lost Mode" heading.




Read the information and tap the "Continue" button.



Please enter a phone number that the person who found the device can reach you and tap the "Next" button. Tap "Use an e-mail address" to be contacted by your e-mail address instead of a phone number.





Customize the lost message and tap the "Activate" button to complete the process.



4. Removing the Device


Select your device by following Find -> Items on your iPhone/iPad. Scroll down the screen and tap the "Remove Item" button.






5. Display of Device Serial Number

Select your device by following Find -> Items on your iPhone/iPad. You can scroll down the screen to display the device serial number.





Battery and Cover

1. Opening the Cover

Split the plastic case of the device in half at the notch on the side edge.



2. Battery Replacement

1. Split the plastic case of the device in half at the notch on the side edge.

2. Remove the old battery from its socket and place the new battery into the socket. Press the cover back into place, aligning it properly. Ensure that the poles are oriented correctly when inserting the new battery into the battery compartment.



Frequently Asked Questions

1. How to track the device location?

A device can be found by other Apple devices that are part of the "Find My" network when it is disconnected from its user for a while. The user can track the location of the device using the "Find My" app.

2. What precautions are taken to prevent someone from tracking me?

If it is detected that a device that is not with its user moves with you for a while, you will be informed in two different ways:

- If you have an iPhone or iPad, the "Find My" app will notify you that there is a device on you.
- The device will sound a "beep" sound after a while, letting you know that there is a device on you.

3. How is the privacy of my data protected?

The location of your device can only be seen by you. Your location data is never stored on the device. The devices that transmit your device's location also remain anonymous, and location data is sent encrypted end-to-end.

4. What is the 'Find My' network and how does it work?

The Apple "Find My" network provides an easy and secure way to locate compatible personal items on a map using the "Find My" app on your iPhone, iPad, or Mac, or the "Find My" app on your Apple Watch. All you need to do is pair your device with the "Find My" app to start using the network. If your item is lost, you can activate your device in 'Lost Mode' to send a message and your contact information to anyone nearby. The 'Find My' network is encrypted and anonymous, so no one, not even Apple, can see your location data.

5. Is it accurate the location information shared by the device?

The location information shared by the device is highly accurate, thanks to the "Find My" technology.

6. Is the location information shared by the device instantaneous

Yes

7. How long is the battery life?

It is approximately 6 months depending on your frequency of use.

Common Issues and Solutions

1. I can't pair the device.

- Make sure to remove the plastic protective strip on the device battery.

- Make sure the device battery is at a sufficient level.

- Make sure the device is turned on.

-Reset the device to factory settings and try pairing again.

2. The device makes no sound.

- Make sure to remove the plastic protective strip on the device battery.

- Make sure the device's battery is at a sufficient level.

- Make sure the device is turned on.

- Make sure to insert the PCB properly and close the cover properly.

Safety

WARNING: KEEP THE BATTERIES OUT OF REACH OF CHILDREN.

Swallowing the battery can cause serious injury or death within as short as 2 hours due to chemical burns and potential perforation of the esophagus.

If you suspect that your child has swallowed a battery, call emergency medical services immediately.

Rated voltage 3V

Rated current ~175 mAh



KEEP THE BATTERIES OUT OF REACH OF CHILDREN.

Keep the device in its original package until ready for use.

Call local medical centers for treatment information.

Do not use the device if the device cover is not closed securely.

Dispose of the used batteries immediately and safely. Even if the batteries are dead, it can still be dangerous.

There is a risk of fire and burns.

Do not recharge, disassemble, heat (-20°C +70°C) or burn the battery.

CAUTION: Do not swallow the battery. This product contains a coin/button cell battery. If a coin/button battery is swallowed, it can cause serious internal burns within just 2 hours and may lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, do not use the product and keep it away from children. If you think batteries may have been swallowed, seek medical treatment immediately. Do not use the wrong type of battery.

Legal Disclaimer

The use of the 'Works with Apple Find My' badge indicates that the product is specifically designed to operate with the technology specified in the badge, and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or the use of this product, or its conformity to safety and regulatory standards.

Copyright

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS, and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the United States and other countries and is available through a license.

Compatibility Statement

The latest version of iOS, iPadOS, or macOS is recommended for using the Apple Find My app to locate this item


RoHS
COMPLIANT